

Automatic Target Detection (ATD)& Recognition (ATR)

Centre for Airborne System – IES Project

Joe Wilson Thamiyan C
RANGSONS AEROSPACE PVT LTD | BENGALORE

Automatic Target Detection (ATD) & Recognition (ATR) System

ATD/ATR is a computer vision-based system that detects, extracts, and recognizes defense targets.

(ATD: Ammunition Dump, Blastpen, Bridge, Cooling Tower, Destroyer, Frigate, Merchant Ship, Submarine, Switch Gear Yard, Tank, Hangar, Helipad, Military Aircraft, Passenger Aircraft, Runway Mark, Storage Tank, Tarmac, Transport Aircraft, Vehicle).

(ATR: C17, C130, F16, Mirage, Training Aircraft, Single Rotor Helicopter, Double Rotor Helicopter) from images.

1. High-Level Architecture

The (ATD/ATR) system consists of multiple components working together in real time. The key components are:

- Data Acquisition (Open-Source platform)
- Environment Setup through offline mode
- Choosing the annotation tools
- Data Preprocessing
- Docker container included (DGX A100)
- Computer Vision-based Object-Detection
- Visualization & Inference

2. Technical Architecture

This section details the technology stack and workflow of the (ATR/ATR) object-detection system.

Technology Stack:

- Data Acquisition: Google-Earth / UMBRA (SAR) Images.
- Data Open source: DOTA / Roboflow
- Environment Setup: PYPI package / Docker Image / Standalone mode.
- Annotation Tools: Ro-labeling / X-any labeling.
- Deep learning Model: REDET (Supporting) / STD+HVIT (provided) / Mask-RCNN (POC) Camouflaged.
- Language: Python
- Framework: Pytorch
- Docker container name: redet-experiment

End-to-End Workflow Components:

1. Data Acquisition Module:

- Description: Acquires data from various sources, including Google-Earth, DOTA, RoboFlow, and UMBRA (SAR) images.
- Functionality: Data ingestion, preprocessing, and format conversion.
- Resolution: Max 8000 ~ 4000 dimensional


- Angle of Capture: Must ensure that the required targets are visible from different angle



Preview of ATD targets



Preview of ATR targets



Preview of SAR targets (Only Aircraft)



Preview of IR targets

2. Environment Setup:

- Approximately 350+ libraries to bring through offline mode.

3. Annotation Tool:

- Ro-labeling tool: Use for annotating the images with OBB direction.
- X-AnyLabeling tool: To verify, export the DOTA Format, and Visualization crop images.

4. Data Preprocessing Module:

- Description: Preprocesses the acquired data to enhance image quality and prepare it for object detection.
- Functionality: Image resizing, noise reduction, contrast enhancement.

Code snippet:

Script-1: Common separate function

```
import os
path = r"D:\Dataset\JOE\DOTA\labels"
for i in os.listdir(path):
    try:
        with open(path+ "/" + i) as f:
            data = f.read()
            data = data.replace(","," ")
        with open(path+ "/" + i,"w") as f:
            f.write(data)
    except:
        print(i)
print("Successfully completed")
```

Script-2: Count Instance for target classes

```
import os
import pandas as pd
path1 = r"C:\Users\dev-2\Joe\dataset\LIVE\train_general_classes\reworks\merged-overall\labels"
unique_labels = []
labels_count = {}
file_count = 0
for i in os.listdir(path1): # filename: [I000001, I000002, I000003]
    try:
        file_count += 1
        with open(path1 + "/" + i) as f:
            data = f.readlines() # annotation values: (x1,y1), (x2,y2), (x3,y3), (x4,y4),
            class_label, difficulty
            count = 0
            for j in data:
                split_data = j.split(" ") # space separated values or comma separated
                values.
                unique_labels.append(split_data[8]) # dict: {target_classes} filter the
                unique_classes
    except:
        pass

disc=list(unique_labels)

for k in disc:
    if k in labels_count:
        labels_count[k]+=1
    else:
        labels_count[k]=1
print("target_classes:", labels_count)

# Convert into DataFrame
df=pd.DataFrame(list(labels_count.items()),columns=['value','count'])
print(df)
```

Script-3: Choosing the selected classes in the txt file and moving into designation path

```
import os
import shutil

lst_=['Runway_Mark']

path = r"\90.0.100.238\isr\Joe\dataset-DGX-master\val-20240906\labels"
new_path = r"\90.0.100.238\isr\Joe\dataset-DGX-master\ac"
for i in os.listdir(path):
    try:
        if i.endswith(".txt"):
            with open(os.path.join(path,i)) as f:
                labels = f.readlines()

            for row_number,label in enumerate(labels,start = 1):
                parts = label.strip().split()
                coordinates = list(map(float,parts[:8]))
                class_name = parts[8]
                if class_name in lst_:
                    mm = path+"/"+i[:-4]
                    shutil.copy(path+"/"+i,new_path)
                    shutil.copy(mm +".jpg",new_path)
                    break
    except:
        print(i)
```

Script-4: Moving label its corresponding all images into new directory

```
import os
import shutil
from tqdm import tqdm

img_src_path = r"./val_images_rgb_20250228/6/IMAGES/"
txt_src_path = r"./val_labels_rgb_20250228/6/labelTxt/"

des_txt_src_path = "./val_labels_rgb_20250228/6/test/"

split_data = [i.split('.txt')[0] for i in os.listdir(txt_src_path) if i.endswith('.txt')]

for i in tqdm(split_data):
    try:
        if os.path.exists(os.path.join(txt_src_path, i + '.txt')):
            shutil.copy(os.path.join(img_src_path, i + '.jpg'), des_txt_src_path + i +'.jpg')
    except:
        print(i)
```

Script-5: Removing the unwanted labels in the txt file

```
path = r"D:\Dataset\JOE\ATR\USA-Dataset\verification\txt"

lst_=['Helipad', 'Hangar', 'Military_Aircraft', 'Storage', 'Blastpen', 'Doomed_Fuel_Tank']

for i in os.listdir(path):
    try:
        if i.endswith(".txt"):
            with open(os.path.join(path,i)) as f:
                labels = f.readlines()
                line = []
                for row_number,label in enumerate(labels,start = 1):
                    parts = label.split(' ')
                    coordinates = list(map(float,parts[:8]))
                    class_name = parts[8]
                    if class_name not in lst_:
                        line.append(label)
                with open(os.path.join(path,i),"w") as f:
                    f.writelines(line)
    except:
        print(i)
```

Script-6: Rename the filename

```
import os
path = "./classification_dataset/vehicle/"
var = 0
for i in sorted(os.listdir(path)):
    if i.endswith('jpg'):
        strt = i.split(".")
        strts = strt[0] + ".jpg"
        if os.path.isfile(path + strts):
            os.rename(path+i, path+'vehicle_'+str(var)+".jpg")
            var += 1
path = "./classification_dataset/vehicle/"
var = 1
```

Script-6: Crop image based on area of interest (AOI)

```
%%time

import os

import cv2
from PIL import Image

def create_directory(dir_name):
    if not os.path.exists(dir_name):
        os.makedirs(dir_name)

def crop_and_save_image(image_path, annotations, output_dir):
    image = Image.open(image_path)

    for annotation in annotations:
        parts = annotation.strip().split(",")
        if len(parts) != 10:
            continue

        coords = list(map(float, parts[:8]))
        label = parts[8].strip()

        left = min(coords[0::2])
        top = min(coords[1::2])
        right = max(coords[0::2])
        bottom = max(coords[1::2])

        cropped_image = image.crop((left, top, right, bottom))
        label_dir = os.path.join(output_dir, label)
        create_directory(label_dir)
        cropped_image_name = f"{label}_{int(left)}_{int(top)}.jpg"
        cropped_image_path = os.path.join(label_dir, cropped_image_name)
        cropped_image.save(cropped_image_path)

    unique_names = []
    path_1 = "./aoi/"
    for i in os.listdir(path_1):
        unique_names.append(i.split(".")[0])
    unique_names = list(set(unique_names))

    output_dir = "testing_with_google_earth"

    for i in unique_names:
        image_path = path_1 + "/" + i + ".jpg"
        annotations_file = path_1 + "/" + i + ".txt"
        print("****:", annotations_file)
        # annotations_file = path_1 + "/" + i + ".txt"

        annotations = []
        with open(annotations_file, "r") as file:
            for line in file:
                annotations.append(line)
        # print('list:', annotations)
        try:
            crop_and_save_image(image_path, annotations, output_dir)
        except:
            print("incorrect", image_path)
    print("successfully completed")
```

Script-7: Replacing old label into new label

```
import os

label_path = r"C:\Users\dev-2\Joe\dataset\LIVE\train_general_classes\reworks\merged-overall\labels"
for i in os.listdir(label_path):
    try:
        if i.endswith(".txt"):
            with open(os.path.join(label_path,i),"r") as f:
                data = f.readlines()

            new_class_name = "Hangar"
            for row_n,v in enumerate(data,start = 1):
                parts = data[row_n-1].strip().split()
                if parts[8] == "Hanger":
                    parts[8] = new_class_name
                    data[row_n-1] = " ".join(parts) + "\n"

            with open(os.path.join(label_path,i),"w") as f:
                f.writelines(data)
    except:
        print(i)
```

Script-8: Specific filtered text file corresponding respective images copy to new directory

```
import os
import shutil
from tqdm import tqdm

img_src_path = r"./val_images_rgb_20250228/6/IMAGES/"
txt_src_path = r"./val_labels_rgb_20250228/6/labelTxt/"

des_txt_src_path = "./val_labels_rgb_20250228/6/test/"

split_data = [i.split('.txt')[0] for i in os.listdir(txt_src_path) if i.endswith('.txt')]

for i in tqdm(split_data):
    try:
        if os.path.exists(os.path.join(txt_src_path, i + '.txt')):
            shutil.copy(os.path.join(img_src_path, i + '.jpg'), des_txt_src_path + i + '.jpg')
    except:
        print(i)
```

Script-9: Specific filtered Images corresponding respective text file copy to new directory

```
import os
import shutil
from tqdm import tqdm

img_src_path = r"E:\DEMO\val_subClasses\images\additional"
txt_src_path = r"E:\DEMO\train_subClasses\labels"

des_txt_src_path = "E:\\DEMO\\val_subClasses\\images\\addition_txt\\"

split_data = [i.split('.txt')[0] for i in os.listdir(txt_src_path) if i.endswith('.txt')]


for i in tqdm(split_data):
    try:
        if os.path.exists(os.path.join(img_src_path, i + '.jpg')):
            shutil.copy(os.path.join(txt_src_path, i + '.txt'), des_txt_src_path + i +'.txt')
    except:
        print(i)
```

5. Object Detection Module:

- Description: Detects and extracts potential targets from the preprocessed images.
- Functionality: Object detection, feature extraction, and classification.
- Model: REDET, STD+HVIT

About Model: Rotation-Equivariant Detector (REDET)


- Overall architecture of the proposed rotation-equivariant detector. We first adopt the rotation-equivariant backbone to extract rotation-equivariant features, followed by an RPN and ROI Transformer (RT) to generate RRois. Then we use a novel Rotation-invariant RoI Align.
- (RiROI Align) to produce rotation-invariant features for RoI-wise classification and bounding box (BBox) regression. Rotation-equivariant feature maps. Under the cyclic group CN, the rotation-equivariant feature maps with the size (K, N, H, W) have N orientation channels, and each orientation channel is corresponding to an element in CN.
- The proposed RiRoI Align consists of two parts: spatial alignment and orientation alignment. For and RRoi (x, y, w, h, O), spatial alignment warps the RRoi from the spatial dimension, while orientation alignment circularly switches orientation channels and interpolates features to produce completely rotation-invariant features.



- We worked on 3 backbones for check the performance of the model (RESNET-50, 101, 152).
- Changes in the parameters like Optimizer, Learning rate, Batch size, epochs.

About Model: Spatial Transform Decoupling (STD+HViT)

- Spatial Transform Decoupling (STD), providing a simple-yet-effective solution for oriented object detection with ViTs.
- Built upon stacked ViT blocks, STD utilizes separate network branches to predict the position, size, and angle of bounding boxes, effectively harnessing the spatial transform potential of ViTs in a divide-and-conquer fashion.
- Check this model on DOTA benchmark of object detection in Aerial image on DOTA, this model is the 2nd rank on DOTA dataset with mAP (82.24%)



As per model changes which required to our use case:

- We worked on 3-backbone for check the performance of the model (Orientient FRCNN, ViT, HiViT).
- Changes in the parameters like Optimizer, Learning rate, Batch-size, and epochs etc.

6. Infrastructure:

- Containerization: Docker
- Container Name: redet_experiment
- Image Name: orcn/iisc
- Container ID: d56dbc843ede
- GPU: NVIDIA DGX A100

Docker Module Workflow:

Step-1: Login into DGX environment passed through the credential.

```
C:\Users\dev-2>ssh ajay@192.168.0.129
ajay@192.168.0.129's password:
Welcome to NVIDIA DGX Server Version 5.4.2 (GNU/Linux 5.4.0-137-generic x86_64)

System information as of Monday 26 May 2025 10:53:09 AM IST

System load: 0.8          Processes:           2507
Usage of /: 73.7% of 1.72TB Users logged in:      1
Memory usage: 0%          IPv4 address for docker0: 172.17.0.1
Swap usage:  0%          IPv4 address for enp22s0: 192.168.0.129

The system has 0 critical alerts and 12 warnings. Use 'sudo nvsm show alerts' for more details.

The programs included with the Ubuntu system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*copyright.

Ubuntu comes with ABSOLUTELY NO WARRANTY, to the extent permitted by
applicable law.

The programs included with the Ubuntu system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*copyright.

Ubuntu comes with ABSOLUTELY NO WARRANTY, to the extent permitted by
applicable law.

Last login: Mon May 26 09:49:58 2025 from 192.168.0.144
Could not chdir to home directory /home/ajay: Permission denied
To run a command as administrator (user "root"), use "sudo <command>".
See "man sudo_root" for details.

-bash: /home/ajay/.bash_profile: Permission denied
ajay@ubuntu:/$
ajay@ubuntu:/$
ajay@ubuntu:/$
```

Step-2: List out the all Docker container

```
ajay@ubuntu:~$ docker ps -a
WARNING: Error loading config file: /home/ajay/.docker/config.json: open /home/ajay/.docker/config.json: permission denied
CONTAINER ID   IMAGE               COMMAND                  CREATED             STATUS              PORTS                               NAMES
ae84082a4831   07357d0eff54   "/opt/nvidia/nvidia_..."   3 weeks ago        Exited (0) 3 weeks ago
56a4440c9abc   orcn/iisc:version2   "bash"                  4 months ago       Exited (2) 4 weeks ago
196b32d50837   eoir/iisc:version1   "/opt/nvidia/nvidia_..."   4 months ago       Exited (2) 4 weeks ago
4ffe7cbd9545   onscd/iisc:version1   "bash"                  4 months ago       Exited (2) 4 weeks ago
15591bfb6c6e   openearth/iisc:version1   "bash"                  5 months ago       Exited (2) 4 weeks ago
000ab5cf4e99   srgbfir/v2:latest    "/opt/nvidia/nvidia_..."   5 months ago       Exited (137) 7 weeks ago
fafd45c1a499   std_cabs/iisc:version2   "/opt/nvidia/nvidia_..."   5 months ago       Up 2 days
ec544123ef47   sarobjdet/iisc:version1   "/opt/nvidia/nvidia_..."   5 months ago       Exited (0) 4 weeks ago
e5989f3a0300   onscd/iisc:version1   "bash"                  6 months ago       Exited (127) 2 weeks ago
c44de509ff09   onscd/iisc:version1   "bash"                  12 months ago      Exited (2) 7 days ago
78e24df02b2c   orcn/iisc:version2   "bash"                  13 months ago      Up About an hour
2d57729f52ad   nvcr.io/nvidia/pytorch:22.12_2-py3   "/opt/nvidia/nvidia_..."   14 months ago      Exited (2) 4 weeks ago
ab000dc49f473  csknet/iisc:version1   "/opt/nvidia/nvidia_..."   16 months ago      Exited (0) 4 weeks ago
616f31a0278f   nvcr.io/nvidia/pytorch:22.12-py3   "/opt/nvidia/nvidia_..."   19 months ago      Exited (0) 4 weeks ago
ajay@ubuntu:~$
```

Start the container cmd: docker start redet_experiment

Attach the container cmd: docker attach redet_experiment

Step-3: Launched the jupyter-lab in the container


```
Cmd: jupyter-lab -ip=0.0.0.0 -port=8888 -no-browser -NotebookApp.token='123'  
-allow-root
```

Step-4: Hit the IP-address in any browser

```
192.168.0.129: port no
```

Step-5: Data Transferring local into DGX

Tool: Used the tool on Win SCP



```
Docker cmd: docker cp ./local_path_redet_experiment:/raid/home/joe/folderName  
(Local to Docker)
```

```
Docker cmd: docker cp redet_experiment:/raid/home/joe/folderName  
./local_path_folderName  
(Docker to local)
```

```
Docker cmd: ls -l | wc -l # To check the total no.of count in the folder
```

Step-6: Split for train, Val, and test using img_split.py in the tools folder

Path: cd tools/data/dota/split/split_configs

Open: vi ms_trainval.json

```
root
  nproc 10
  img_dirs [] 1 item
    0 "data/GEDR/ATR_EO/train/images/"
  ann_dirs [] 1 item
    0 "data/GEDR/ATR_EO/train/labels/"
  sizes [] 1 item
    0 3000
  gaps [] 1 item
    0 512
  rates [] 3 items
    0 0.5
    1 1
    2 1.5
  img_rate_thr 0.6
  iof_thr 0.7
  no_padding false
  padding_value [] 3 items
    0 104
    1 116
    2 124
  save_dir "data/GEDR/split_EO_data_13-05-2025/train/"
  save_ext ".png"
```

Path: cd tools/data/dota/split/split_configs

Open: vi ms_val.json

```
root
  nproc 10
  img_dirs [] 1 item
    0 "data/GEDR/ATR_EO/val/images"
  ann_dirs [] 1 item
    0 "data/GEDR/ATR_EO/val/labels/"
  sizes [] 1 item
    0 3000
  gaps [] 1 item
    0 512
  rates [] 3 items
    0 0.5
    1 1
    2 1.5
  img_rate_thr 0.6
  iof_thr 0.7
  no_padding false
  padding_value [] 3 items
    0 104
    1 116
    2 124
  save_dir "data/GEDR/split_EO_data_13-05-2025/val/"
  save_ext ".png"
```

Cmd: python tools/data/dota/split/img_split.py --base-json tools/data/dota/split/split_configs/ms_trainval.json

Cmd: python tools/data/dota/split/img_split.py --base-json tools/data/dota/split/split_configs/ms_val.json

Step-7: Modify the config.py files

```
_base_ = [
    '../_base_/datasets/hrsc.py', '../_base_/schedules/schedule_3x.py',
    '../_base_/default_runtime.py'
]

angle_version = 'le90'

model = dict(
    type='ReDet',
    backbone=dict(
        type='ReResNet',
        depth=50,
        num_stages=4,
        out_indices=(0, 1, 2, 3),
        frozen_stages=1,
        style='pytorch',
        pretrained='./work_dirs/re_resnet50_c8_batch256-25b16846.pth'),
    neck=dict(
        type='ReFPN',
        in_channels=[256, 512, 1024, 2048],
        out_channels=256,
        num_outs=5),
    rpn_head=dict(
        type='RotatedRPNHead',
        in_channels=256,
        feat_channels=256,
        version=angle_version,
        anchor_generator=dict(
            type='AnchorGenerator',
            scales=[8],
            ratios=[0.5, 1.0, 2.0],
            strides=[4, 8, 16, 32, 64]),
        bbox_coder=dict(
            type='DeltaXYWHBBoxCoder',
            target_means=[.0, .0, .0, .0],
            target_stds=[1.0, 1.0, 1.0, 1.0]),
```

```
        loss_cls=dict(
            type='CrossEntropyLoss', use_sigmoid=True, loss_weight=1.0),
        loss_bbox=dict(type='SmoothL1Loss', beta=1.0 / 9.0, loss_weight=1.0)),
    roi_head=dict(
        type='RoITransRoIHead',
        version=angle_version,
        num_stages=2,
        stage_loss_weights=[1, 1],
        bbox_roi_extractor=[
            dict(
                type='SingleRoIExtractor',
                roi_layer=dict(
                    type='RoIAlign', output_size=7, sampling_ratio=0),
                out_channels=256,
                featmap_strides=[4, 8, 16, 32]),
            dict(
                type='RotatedSingleRoIExtractor',
                roi_layer=dict(
                    type='RiRoIAlignRotated',
                    out_size=7,
                    num_samples=2,
                    num_orientations=8,
                    clockwise=True),
                out_channels=256,
                featmap_strides=[4, 8, 16, 32]),
        ],
        bbox_head=[
            dict(
                type='RotatedShared2FCBBoxHead',
                in_channels=256,
                fc_out_channels=1024,
                roi_feat_size=7,
                num_classes=1,
                bbox_coder=dict(
                    type='DeltaXYWHABBoxCoder',
                    angle_range=angle_version,
```

```

        norm_factor=2,
        edge_swap=True,
        target_means=[0., 0., 0., 0., 0.],
        target_stds=[0.1, 0.1, 0.2, 0.2, 0.1]),
        reg_class_agnostic=True,
        loss_cls=dict(
            type='CrossEntropyLoss',
            use_sigmoid=False,
            loss_weight=1.0),
        loss_bbox=dict(type='SmoothL1Loss', beta=1.0,
                      loss_weight=1.0)),
        dict(
            type='RotatedShared2FCBBoxHead',
            in_channels=256,
            fc_out_channels=1024,
            roi_feat_size=7,
            num_classes=1,
            bbox_coder=dict(
                type='DeltaXYWHAOBBoxCoder',
                angle_range=angle_version,
                norm_factor=None,
                edge_swap=True,
                proj_xy=True,
                target_means=[0., 0., 0., 0., 0.],
                target_stds=[0.05, 0.05, 0.1, 0.1, 0.05]),
            reg_class_agnostic=False,
            loss_cls=dict(
                type='CrossEntropyLoss',
                use_sigmoid=False,
                loss_weight=1.0),
            loss_bbox=dict(type='SmoothL1Loss', beta=1.0, loss_weight=1.0))
        ],
        train_cfg=dict(
            rpn=dict(
                assigner=dict(
                    type='MaxIoUAssigner',

```

```
        pos_iou_thr=0.7,  
        neg_iou_thr=0.3,  
        min_pos_iou=0.3,  
        match_low_quality=True,  
        ignore_ifr_thr=-1),  
    sampler=dict(  
        type='RandomSampler',  
        num=256,  
        pos_fraction=0.5,  
        neg_pos_ub=-1,  
        add_gt_as_proposals=False),  
    allowed_border=0,  
    pos_weight=-1,  
    debug=False),  
    rpn_proposal=dict(  
        nms_pre=2000,  
        max_per_img=2000,  
        nms=dict(type='nms', iou_threshold=0.7),  
        min_bbox_size=0),  
    rcnn=[  
        dict(  
            assigner=dict(  
                type='MaxIoUAssigner',  
                pos_iou_thr=0.5,  
                neg_iou_thr=0.5,  
                min_pos_iou=0.5,  
                match_low_quality=False,  
                ignore_ifr_thr=-1,  
                iou_calculator=dict(type='BboxOverlaps2D')),  
            sampler=dict(  
                type='RandomSampler',  
                num=512,  
                pos_fraction=0.25,  
                neg_pos_ub=-1,  
                add_gt_as_proposals=True),  
            pos_weight=-1,
```

```

        debug=False),
    dict(
        assigner=dict(
            type='MaxIoUAssigner',
            pos_iou_thr=0.5,
            neg_iou_thr=0.5,
            min_pos_iou=0.5,
            match_low_quality=False,
            ignore_iou_thr=-1,
            iou_calculator=dict(type='RBboxOverlaps2D')),
        sampler=dict(
            type='RRandomSampler',
            num=512,
            pos_fraction=0.25,
            neg_pos_ub=-1,
            add_gt_as_proposals=True),
        pos_weight=-1,
        debug=False)
    ],
test_cfg=dict(
    rpn=dict(
        nms_pre=2000,
        max_per_img=2000,
        nms=dict(type='nms', iou_threshold=0.7),
        min_bbox_size=0),
    rcnn=dict(
        nms_pre=2000,
        min_bbox_size=0,
        score_thr=0.05,
        nms=dict(iou_thr=0.1),
        max_per_img=2000)))

img_norm_cfg = dict(
    mean=[123.675, 116.28, 103.53], std=[58.395, 57.12, 57.375], to_rgb=True)
train_pipeline = [
    dict(type='LoadImageFromFile'),

```

```

        dict(type='LoadAnnotations', with_bbox=True),
        dict(type='RResize', img_scale=(800, 512)),
        dict(type='RRandomFlip', flip_ratio=0.5),
        dict(type='Normalize', **img_norm_cfg),
        dict(type='Pad', size_divisor=32),
        dict(type='DefaultFormatBundle'),
        dict(type='Collect', keys=['img', 'gt_bboxes', 'gt_labels'])

    ]
test_pipeline = [
    dict(type='LoadImageFromFile'),
    dict(
        type='MultiScaleFlipAug',
        img_scale=(800, 512),
        flip=False,
        transforms=[
            dict(type='RResize'),
            dict(type='Normalize', **img_norm_cfg),
            dict(type='Pad', size_divisor=32),
            dict(type='DefaultFormatBundle'),
            dict(type='Collect', keys=['img'])
        ])
]

data = dict(
    train=dict(pipeline=train_pipeline),
    val=dict(pipeline=test_pipeline),
    test=dict(pipeline=test_pipeline))

evaluation = dict(interval=12, metric='mAP')
optimizer = dict(lr=0.01)

```

```
../_base_/datasets/dotav1.py

# dataset settings
dataset_type = 'DOTADataset'
data_root = 'data/GEDR/'

img_norm_cfg = dict(
    mean=[123.675, 116.28, 103.53], std=[58.395, 57.12, 57.375], to_rgb=True)

train_pipeline = [
    dict(type='LoadImageFromFile'),
    dict(type='LoadAnnotations', with_bbox=True),
    # dict(type='RandomGrayscale', prob=0.1, channel_weights=(0.25,0.5,0.25)),
    dict(type='RResize', img_scale=(512, 512)),
    dict(type='RRandomFlip', flip_ratio=0.5),
    dict(type='Normalize', **img_norm_cfg),
    dict(type='Pad', size_divisor=32),
    dict(type='DefaultFormatBundle'),
    dict(type='Collect', keys=['img', 'gt_bboxes', 'gt_labels'])
]

test_pipeline = [
    dict(type='LoadImageFromFile'),
    dict(
        type='MultiScaleFlipAug',
        img_scale=(512, 512),
        flip=False,
        transforms=[
            dict(type='RResize'),
            dict(type='Normalize', **img_norm_cfg),
            dict(type='Pad', size_divisor=32),
            dict(type='DefaultFormatBundle'),
            dict(type='Collect', keys=['img'])
        ])
]

data = dict(
    samples_per_gpu=1,
    workers_per_gpu=16,
    train=dict(
        type=dataset_type,
```

```

        # ann_file=data_root + 'train/annfiles/',
        # img_prefix=data_root + 'train/images/',
        ann_file=data_root + 'ATR_E0/train/labels',
        img_prefix=data_root + 'ATR_E0/train/images/',
        pipeline=train_pipeline),
    val=dict(
        type=dataset_type,
        ann_file=data_root + 'ATR_E0/val/labels',
        img_prefix=data_root + 'ATR_E0/val/images',
        pipeline=test_pipeline),
    test=dict(
        type=dataset_type,
        ann_file=data_root + 'ATR_E0/val/labels',
        img_prefix=data_root + 'ATR_E0/val/images',
        pipeline=test_pipeline))

```

```

./__base__/schedules/schedule_1x.py
# dataset settings
dataset_type = 'DOTADataset'
data_root = 'data/GEDR/'
img_norm_cfg = dict(
    mean=[123.675, 116.28, 103.53], std=[58.395, 57.12, 57.375], to_rgb=True)
train_pipeline = [
    dict(type='LoadImageFromFile'),
    dict(type='LoadAnnotations', with_bbox=True),
    # dict(type='RandomGrayscale', prob=0.1, channel_weights=(0.25,0.5,0.25)),
    dict(type='RResize', img_scale=(512, 512)),
    dict(type='RRandomFlip', flip_ratio=0.5),
    dict(type='Normalize', **img_norm_cfg),
    dict(type='Pad', size_divisor=32),
    dict(type='DefaultFormatBundle'),
    dict(type='Collect', keys=['img', 'gt_bboxes', 'gt_labels'])
]
test_pipeline = [
    dict(type='LoadImageFromFile'),
    dict(

```

```
        type='MultiScaleFlipAug',
        img_scale=(512, 512),
        flip=False,
        transforms=[
            dict(type='RResize'),
            dict(type='Normalize', **img_norm_cfg),
            dict(type='Pad', size_divisor=32),
            dict(type='DefaultFormatBundle'),
            dict(type='Collect', keys=['img'])
        ])
    ]
data = dict(
    samples_per_gpu=1,
    workers_per_gpu=16,
    train=dict(
        type=dataset_type,
        # ann_file=data_root + 'train/annfiles/',
        # img_prefix=data_root + 'train/images/',
        ann_file=data_root + 'ATR_E0/train/labels',
        img_prefix=data_root + 'ATR_E0/train/images/',
        pipeline=train_pipeline),
    val=dict(
        type=dataset_type,
        ann_file=data_root + 'ATR_E0/val/labels/',
        img_prefix=data_root + 'ATR_E0/val/images/',
        pipeline=test_pipeline),
    test=dict(
        type=dataset_type,
        ann_file=data_root + 'ATR_E0/val/labels',
        img_prefix=data_root + 'ATR_E0/val/images',
        pipeline=test_pipeline))
```

```
tools/dist_train.sh

#!/usr/bin/env bash

CONFIG=$1

GPUS=$2

NNODES=${NNODES:-1}

NODE_RANK=${NODE_RANK:-0}

PORT=${PORT:-29502}

MASTER_ADDR=${MASTER_ADDR:-"127.0.0.1"}


PYTHONPATH="$(dirname $0)/..":$PYTHONPATH \
python -m torch.distributed.launch \
--nnodes=1 \
--node_rank=$NODE_RANK \
--master_addr=$MASTER_ADDR \
--nproc_per_node=$GPUS \
--master_port=$PORT \
$(dirname "$0")/train.py \
$CONFIG \
--seed 0 \
--launcher pytorch ${@:3}
```

Steps: **Train the Model**

Cmd: CUDA_VISIBLE_DEVICES=0,1,2,3 tools/dist_train.sh configs/redet/ redet_re50_refpn_1x_dota_le90.py 4

Experimental:


Method: Multi-Scale (MS) - ATD	ATD – (Automatic Target Detection)										
	Hyper-Parameter										
Model	Backbone	Dataset	Img_Count	Categories	Img_Size	Batch_size	Epochs	Experiment	Optimizer	LR	mAP(%)
REDET	RESNET-50	Google Earth	6488	20	512	8	12	Exp0001	SGD	0.01	53.5
	RESNET-101			20	512	8	12	Exp0002	SGD	0.01	56.1
	RESNET-152			20	512	8	12	Exp0003	SGD	0.01	35.9

Method: Multi-Scale (MS) - ATR	ATR - (Automatic Target Recognition)										
	Hyper-Parameter										
Model	Backbone	Dataset	Img_Count	Categories	Img_Size	Batch_size	Epochs	Experiment	Optimizer	LR	mAP(%)
REDET	RESNET-50	Google Earth	4984	8	512	8	12	Exp0001	SGD	0.01	84.0
	RESNET-101			8	512	8	12	Exp0002	SGD	0.01	85.8
	RESNET-152			8	512	8	12	Exp0003	SGD	0.01	76.0


STD+HVIT (Automatic Target Recognition)

Method : Multi-Scale (MS)	Hyper-Parameter											
	Model	Backbone	Dataset	Img_Count	Categories	Img_Size	Batch_Size	Epochs	Experiment	pretrain	Optimizer	LR
REDET	RESNET-50	GEDR (Google-Earth)	6488	8	1024	8	12	Exp01	Resnet-50	SGD	0.01	84.0
STD	Oriented Faster-RCNN	DOTAV1.5				8	12	Exp01	orcnn_std_hvit	AdamW	0.00025	82.9

Confusion Matrix:



REDET




STD+HVIT

7. Inference Module



ORIGINAL IMAGE



REDET



STD



ORIGINAL IMAGE




REDET




STD



ORIGINAL IMAGE




REDET




STD



ORIGINAL IMAGE



REDET



STD



ORIGINAL IMAGE



REDET



STD



ORIGINAL IMAGE



REDET



STD



ORIGINAL IMAGE



REDET



STD

Production

ATD/ATR – (Automatic Target Detection & Recognition) (Hyper parameters)												
Method: Multi Scale (MS)	Model	TypeOfDetection	Backbone	Dataset	Img_count	Categories	Img_size	Batch_size	Epochs	Optimizer	LR	mAP(%)
REDET	ATD	RESNET- 50 + CUTMIX	GEDR		20		16	12	SGD	0.01	85.3	
REDET	ATR	RESNET- 50	GEDR		8		16	12	SGD	0.01	49	
STD+ViT	ATD	ViT	GEDR		20		8	12	AdamW	0.00005	74.5	
STD+HViT	ATR	HViT	GEDR		8		2	12	AdamW	0.00006	89.5	

InfraRed (IR) Image

ATD – (Automatic Target Detection)

Description: This model is semi-supervised RGB-to-IR Image to Image Translation. Model Provides IR images at 4 level with different contrast.

Training: Co-registered EO and IR images without any annotations.

Dataset: Google Earth

Inference:

- Input: EO images
- Output: It will translate the EO images into IR image at 4 levels

1. Infrastructure:

- Containerization: Docker
- Image Name: srgb2ir_v2:latest
- Container Name: srg2ir
- Container ID: 07357d0eff54
- Environment Name: UNSB
- URL: 192.168.0.129:8157
- Password: Token
- GPU: NVIDIA DGX A100

Docker Module Workflow:

Step-1: Login into DGX environment passed through the credential.

```
C:\Users\dev-2>ssh ajay@192.168.0.129
ajay@192.168.0.129's password:
Welcome to NVIDIA DGX Server Version 5.4.2 (GNU/Linux 5.4.0-137-generic x86_64)

System information as of Monday 26 May 2025 10:53:09 AM IST

System load: 0.8      Processes:          2507
Usage of /: 73.7% of 1.72TB  Users logged in:      1
Memory usage: 0%          IPv4 address for docker0: 172.17.0.1
Swap usage: 0%          IPv4 address for enp226s0: 192.168.0.129

The system has 0 critical alerts and 12 warnings. Use 'sudo nvsm show alerts' for more details.

The programs included with the Ubuntu system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/*copyright.

Ubuntu comes with ABSOLUTELY NO WARRANTY, to the extent permitted by
applicable law.

The programs included with the Ubuntu system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/*copyright.

Ubuntu comes with ABSOLUTELY NO WARRANTY, to the extent permitted by
applicable law.

Last login: Mon May 26 09:49:58 2025 from 192.168.0.144
Could not chdir to home directory /home/ajay: Permission denied
To run a command as administrator (user "root"), use "sudo <command>".
See "man sudo_root" for details.

-bash: /home/ajay/.bash_profile: Permission denied
ajay@ubuntu:/$
ajay@ubuntu:/$
ajay@ubuntu:/$
```

Step-2: List out the all Docker container

```
ajay@ubuntu:~$ docker ps -a
WARNING: Error loading config file: /home/ajay/.docker/config.json: open /home/ajay/.docker/config.json: permission denied
CONTAINER ID        IMAGE               COMMAND             CREATED            STATUS              PORTS
ae84082a4831      07357deff5d4      "/opt/nvidia/nvidia_-"   3 weeks ago       Exited (0) 3 weeks ago
56a4440c9abc      orccnn/lisc:version2    "bash"              4 months ago      Exited (2) 4 weeks ago
196033d9b837      eoir/lisc:version1     "/opt/nvidia/nvidia_-"   4 months ago      Exited (2) 4 weeks ago
4ffe7cbd9545      onscd/lisc:version1    "bash"              4 months ago      Exited (2) 4 weeks ago
15591fbfc6ce      openearth/lisc:version1  "bash"              5 months ago      Exited (2) 4 weeks ago
0bb4ab5cf4ec      srgbfir_v2:latest      "/opt/nvidia/nvidia_-"   5 months ago      Exited (137) 7 weeks ago
fafd45c1a999      std_cabs/lisc:version2  "/opt/nvidia/nvidia_-"   5 months ago      Up 2 days
e544123ef47      sarobjdet/lisc:version1  "/opt/nvidia/nvidia_-"   5 months ago      Exited (0) 4 weeks ago
e983ab7cad2f      segmentation/lisc:version1  "bash"              6 months ago      Exited (127) 4 weeks ago
c44be509bf09      onscd/lisc:version1    "bash"              12 months ago     Exited (255) 7 days ago  8080/tcp, 0.0.0.0:8092->8092/tcp, :::8092->8092/tcp
78e244fb02c2      orccnn/lisc:version2    "bash"              13 months ago     Up About an hour
d57779f523d       nvcr.io/nvidia/pytorch:22.12_2-py3  "/opt/nvidia/nvidia_-"   14 months ago     Exited (2) 4 weeks ago
ab99017473       csknet/lisc:version1     "/opt/nvidia/nvidia_-"   16 months ago     Exited (0) 4 weeks ago
c16f314027bf      nvcr.io/nvidia/pytorch:22.12-py3  "/opt/nvidia/nvidia_-"   19 months ago     Exited (0) 4 weeks ago
ajay@ubuntu:~$
```

Start the container cmd: docker start srg2ir

Attach the container cmd: docker attach srg2ir

Step-3: Launched the jupyter-lab in the container

Cmd: jupyter-lab –ip=0.0.0.0 –port=8157 –no-browser –NotebookApp.token='Token' –allow-root


Command for Inference:

```
python3 inference_batch.py --input_folder ./dummy_input -- output_folder ./dummy_latest --
checkpoint ./translation_weights.pt --a2b 0 --seed 1234 --num_style 5 --synchronized --output_only
--config configs/tir2rgb_folder.yaml
```


Table:

Method: Multi-Scale (MS)	ATD – (Automatic Target Detection) (IR-Image) (Hyper parameters)									
Model	Backbone	Dataset	Img_count	Categories	Img_size	Batch_size	Epochs	Optimizer	LR	mAP(%)
REDET	RESNET-50	Google Earth	2337	8	1024	8	12	SGD	0.01	50.1


Inference:




ORIGINAL IMAGE




REDET




ORIGINAL IMAGE



REDET




ORIGINAL IMAGE




REDET



ORIGINAL IMAGE





ORIGINAL IMAGE



REDET

Synthetic Aperture Radar (SAR – Image)

ATD – (Automatic Target Detection)


1. Infrastructure:

- Containerization: Docker
- Image Name: sarobjdet/iisc:version1
- Container Name: sarobjdet
- Container ID: e8234cc236db
- Environment Name: MSFA
- URL: 192.168.0.129:8888
- Password: 123
- GPU: NVIDIA DGX A100


Table:

Method: Multi-Scale (MS)	ATD – (Automatic Target Detection) (SAR-Image) (Hyper parameters)										
Model	Backbone	Dataset	Img_count	Categories	Img_size	Batch_size	Epochs	Optimizer	LR	mAP(%)	
REDET	RESNET-50	UMBRA	12	1	1024	8	12	SGD	0.01	51.9	

Inference:



ORIGINAL IMAGE



REDET



ORIGINAL IMAGE



REDET